



1. SEE EVERGUARD® SPEC MANUAL TO DETERMINE PERIMETER AND CORNER ZONES.
2. DEFAULTS TO PERIMETER FASTENING RATE.
3. DEFAULTS TO CORNER FASTENING RATE.

FIELD ZONE

PERIMETER ZONE

CORNER ZONE

NTS