


SINGLE-PLY: TPO & PVC



NOTE:

1. SEE EVERGUARD® SYSTEM GUIDELINES IN SPEC MANUAL TO DETERMINE PERIMETER AND CORNER ENHANCMENTS FOR VARIOUS DECK TYPES AND WIND UPLIFT REQUIREMENTS.
2. IF A PORTION OF A BOARD EXTENDS INTO ANOTHER ZONE, IT MUST DEFER TO THE ZONE OF THE GREATER FASTENING PATTERN.
3. OVER APPROVED WOOD DECKS.

GAF

DRILL-TEC™ RHINOBOND® INSULATION FASTENING ZONES

DRAWING #
107B

THIS DETAIL APPLIES TO:
RHINOBOND® SYSTEMS

ISSUE / REVISION DATE
8/17/20

SCALE
N.T.S.

LEGEND

- FIELD ZONE
- PERIMETER ZONE
- CORNER ZONE
- TRANSITION ZONE